


## Installation Instructions

- 1. Fix head / base tracks and all studs according to details on page 2 & 3. Studs must be minimum 63mm x 38mm.
- 2. Apply Protecta FR Coating to all four edges of 1200 x 562mm sheets of 60mm Protecta FR Board and friction fit between the studs. Continue in this manner for the rest of the wall. The horizontal joints should be staggered as shown on page 2.
- 3. Fix particleboard sheets to each side of the wall (minimum 12mm thick) with joints offset as shown on page 3. Fill all gaps between the particleboard and the surrounding construction with Protecta FR Acrylic sealant to the depth of the particleboard.
- 4. Coat all exposed faces of particleboard with Protecta Interior Paint FR-1 to a depth of 220 microns.




painted on exposed side with Protecta Interior

FRR -/60/60


Paint FR-1



Protecta FR Board - Naked Wall using Timber Studs - FRR -/60/60







## VERTICAL SECTION