



FIRESTOP CENTRE

Authorised New Zealand Distributor
Ph (09) 483 4000 www.firestopcentre.co.nz



Report AR23108, Pages 8, 9-11, 29
AS1530.4-2014 AS4072.1-2005

System ID# FC305

Products Firestop Centre Ultra or FIRESTOP
Application Firestop
Construction Firestop

Fire Classification

NOTE: For general instructions on installing FIRESTOP Duct Wrap-38 see [Installation Instructions](#) sheet on Firestop Centre website.

External Fire

Single layer wrap below the floor FRR 60/60/30
Double layer wrap below the floor FRR 120/120/120

NOTE: Where floor FRR is less than above reduce penetration rating to match the floor.




FIRESTOP
Firestop Centre Ltd
657 Great South Road
Penrose, AUCKLAND

Sheet size:
A4

Drawn date & no:
20/5/24

NOTE: Diagram shows 2 layer system, but see details on right for number of layers



External Fire

As a part of our policy of on-going product development and testing, we reserve the right to modify, alter or change product specifications without giving notice. All information contained in this document is given in good faith and is provided for guidance only. Any drawings provided are for illustrative purposes only. As Firestop Centre has no control over the methods or competence of installation and of prevailing site conditions, no warranties, expressed or implied are intended to be given as to the actual performance of the product mentioned or referred to herein and no liability whatsoever will be accepted for any loss, damage or injury arising from the use of the information given.