FIRESTOP CENTRE

Authorised New Zealand Distributor Ph (09) 483 4000 www.firestopcentre.co.nz


Step-by-step installation instructions:

- 1. Ensure the aperture is free from dust and debris.
- 2. Apply AGNI-Seal into the annular gap around the service to the full depth of the wall.
- 3. Apply 30mm x 30mm AGNI-Seal fillet/cone around the service.

AGNI-Seal in a Hebel Wall (min 75mm) TPS Cable Bundle (up to 8) Max FRR -/120/60

System ID# FC304

Page 1 of 2



Technical Information	
Substrate	Min. 75mm Hebel Wall
Service range	8 x TPS cables
Annular gap	5.2 - 15.4mm
AGNI-Products	AGNI-Seal
Protection installation	From both sides of the wall

Compliance Information	
Standards	AS1530.4-2014, AS4072.1-2005
FRR/FRL	-/120/60
Reference	PF24145





8 Clare St Bayswater VIC 3153, AUSTRALIA www.agnitek.com.au

Date

Disclaimer

Agnitek reserves the right to modify product specifications without prior notice due to its ongoing research, development & certification programme. The information in this document is provided in good faith and is intended for guidance purposes only. Any accompanying drawings are solely for illustrative purposes. Since Agnitek cannot oversee installation methods or ensure site conditions, no warranties, expressed or implied, are intended regarding the products' actual performance. We do not accept liability for any loss, damage, or injury from using this information. Please take a look at the test reports displayed on a relevant AGNI-System webpage for all compliance specifics.





Substrate	Min. 75mm Hebel Wall	S
Service range	8 x TPS cables cables	F
Annular gap	5.2 - 15.4mm	R
AGNI-Products	AGNI-Seal	
Protection installation	From both sides of the wall	

Standards	AS1530.4-2014, AS4072.1-2005	
FRR/FRL	-/120/60	
Reference	PF24145	

Date 07.03.2025

8 Clare St Bayswater VIC 3153, AUSTRALIA www.agnitek.com.au

Disclaime

Agnitek reserves the right to modify product specifications without prior notice due to its ongoing research, development & certification programme. The information in this document is provided in good faith and is intended for guidance purposes only. Any accompanying drawings are solely for illustrative purposes. Since Agnitek cannot oversee installation methods or ensure site conditions, no warranties, expressed or implied, are intended regarding the products' actual performance. We do not accept liability for any loss, damage, or injury from using this information. Please take a look at the test reports displayed on a relevant AGNI-System webpage for all compliance specifics.