## **FIRESTOP CENTRE**

Authorised New Zealand Distributor Ph (09) 483 4000 www.firestopcentre.co.nz AGNI-Seal in 13mm Plasterboard Ceiling Steel Pipe up to 50mm diam Up to FRR -/60/60

System ID# FC821

## Step-by-step installation instructions:

- 1. Ensure the aperture is free from dust and debris.
- 2. Exposed side: Install AGNI-Seal into the annular gap between the service and plasterboard to the full depth of the plasterboard.

Unexposed side: Service doesn't penetrate plywood lining.



Technical Information	
Substrate	• Fire-rated plasterboard ceiling (min. one layer of 13mm plasterboard or greater)
Service range	DN up to 50mm steel pipe
Annular gap	2mm - 10mm
AGNI-Products	AGNI-Seal
Protection installation	Asymmetrical - installed on the fire side only

Standards	AS1530.4-2014, AS4072.1-2005
FRR/FRL	-/45/45 in a ceiling with FRR 45/45/45 -/60/60 in a ceiling with FRR 60/60/60
Reference	RIRF24079 AP-085

**Compliance Information** 




8 Clare St Bayswater VIC 3153, AUSTRALIA www.agnitek.com.au

Date 16.08.2024

## Disclaimer

Agnitek reserves the right to modify product specifications without prior notice due to its ongoing research, development & certification programme. The information in this document is provided in good faith and is intended for guidance purposes only. Any accompanying drawings are solely for illustrative purposes. Since Agnitek cannot overse installation methods or ensure site conditions, no warranties, expressed or implied, are intended regarding the products' actual performance. We do not accept liability for any loss, damage, or injury from using this information. Please take a look at the test reports displayed on a relevant AGNI-System webpage for all compliance specifics.

Page 1 of 2



## Disclaimer

Agnitek reserves the right to modify product specifications without prior notice due to its ongoing research, development & certification programme. The information in this document is provided in good faith and is intended for guidance purposes only. Any accompanying drawings are solely for illustrative purposes. Since Agnitek cannot oversee installation methods or ensure site conditions, no warranties, expressed or implied, are intended regarding the products' actual performance. We do not accept liability for any loss, damage, or injury from using this information. Please take a look at the test reports displayed on a relevant AGNI-System webpage for all compliance specifics.

Date 16.08.2024