

FIRESTOP CENTRE

Authorised New Zealand Distributor
Ph (09) 483 4000 www.firestopcentre.co.nz

AGNI-Seal in 1 x 13mm Plasterboard Wall Brass Wingback FRR -/60/60

Step-by-step installation instructions:

- 1. Ensure the aperture is free from dust and debris.
- 2. Apply a 13mm deep seal into the annular space.
- 3. Form a 10mm x 10mm cone of sealant between the wing back and the lining.



System ID# FC849

Technical Information

| Technical information | |
|-------------------------|--|
| Substrate | Min. 90mm timber or steel stud wall with a minimum of one layer of 13mm (or greater) FR plasterboard on each side, with or without insulation. |
| | Min 90mm masonry wall |
| Service range | Brass wingback |
| Annular gap | 3mm - 5,5mm |
| AGNI-Products | AGNI-Seal |
| Protection installation | Asymmetrical - installed on the fire side only |

Compliance Information

| Standards | AS1530.4-2014, AS4072.1-2005 |
|-----------|------------------------------|
| FRR/FRL | -/60/60 |
| Reference | RIRF24068 (AP072) |
| | |
| | |
| | |




8 Clare St Bayswater VIC 3153, AUSTRALIA www.agnitek.com.au


Date

01.08.2024



AGNI-Seal in 1 x 13mm Plasterboard Wall **Brass Wingback**





Technical Information

| reclinical information | |
|-------------------------|--|
| Substrațe | Min. 90mm timber or steel stud wall with a minimum of one layer of 13mm (or greater) FR plasterboard on each side, with or without insulation. |
| | Min 90mm masonry wall |
| Service range | Brass wingback |
| Annular gap | 3mm - 5,5mm |
| AGNI-Products | AGNI-Seal |
| Protection installation | Asymmetrical - installed on the fire side only |

| Standards | AS1530.4-2014, AS4072.1-2005 |
|-----------|------------------------------|
| FRR/FRL | -/60/60 |
| Reference | PF24068 |
| | |
| | |
| | |

Date

01.08.2024

FIRE RATED TECHNOLOGY

8 Clare St Bayswater VIC 3153, AUSTRALIA www.agnitek.com.au

Agnitek reserves the right to modify product specifications without prior notice due to its ongoing research, development & certification programme. The information in this document is provided in good faith and is intended for guidance purposes only. Any accompanying drawings are solely for illustrative purposes. Since Agnitek cannot oversee installation methods or ensure site conditions, no warranties, expressed or implied, are intended regarding the products' actual performance. We do not accept liability for any loss, damage, or injury from using this information. Please take a look at the test reports displayed on a relevant AGNI-System webpage for all compliance specifics.