


Protecta FR Putty Cord - Plasterboard Wall Cable Bundle

Authorised New Zealand Distributor Ph (09) 483 4000 www.firestopcentre.co.nz

Installation Instructions

- Before installing Protecta® FR Putty Cord ensure that the surface of all service penetrations and surrounding construction is wiped clean, dry, free from all loose contaminants, dust, oils and grease.
- 2. Place the Putty Cord around the services so that it seals the services to the wall all the way round.
- Press the Putty Cord into the wall and services with your thumbs to form a fillet or V shape joint, ensuring good contact is made all the way round the services and the wall.
- Insulated cables with copper or aluminium conductors, fibre optic cables or communication cables.
- 5. The putty cord is designed to be easily fitted around service penetrations where the gap around the services is very small, or there is no gap at all so a conventional fire rated sealant is impossible or difficult to fit due to the required depth and backing material. The putty cords are fitted covering the gap around the services and do not need to fill the gap to any required depth.





NOTE: Blanks up to 15mm diameter may be sealed with a 15mm deep cord of Protecta FR Putty on both sides of the wall FRR -/120/120

As a part of our policy of on-going product development and testing, we reserve the right to modify, alter or change product specifications without giving notice. All information contained in this document is given in good faith and is provided for guidance only. Any drawings provided are for illustrative purposes only. As Polyseam has no control over the methods or competence of installation and of prevailing site conditions, no warranties, expressed or implied, is intended to be given as to the actual performance of the product mentioned or referred to herein and no liability whatsoever will be accepted for any loss, damage or injury arising from the use of the information given.

For all technical details on the products specified please refer to the technical data sheets that can be found on www.firestopcentre.co.nz

Signed and approved:



Exova EWFA Assessment Report 53619700-A.2 Page 14 AS1530.4-2014 AS4072.1-2005

System/FPA Register ID# FC349

Products Protecta FR Putty Cord

Application Fire stopping of cables in

flexible walls

Construction Minimum wall thickness of

100mm and comprise steel or timber studs lined on both faces with minimum 1 layer of 13mm

thick board*

Fire & Sound Classification

Cable bundles up to 50mm diam:

Individual cables < 21mm FRR -/120/120 Individual cables > 21mm FRR -/60/60

Single cables up to 21mm diam FRR -/120/120 Single cables up to 80mm diam FRR -/60/60

*FRRs shown are for double layer 13mm walls. Where single layer 13mm walls have an FRR lower than the above then the FRR of the seal must be reduced to match the FRR of the wall.



Polyseam Ltd, 15 St Andrews Road, Huddersfield, West Yorkshire, HD1 6SB

Tel: +44 (0) 148 4421036

Email: post.uk@polyseam.com

Sheet size:	Drawn date & no:
A4	29/5/18
Scale:	Drawn by:
NTS	K.B